

Installation Instructions

AE01K-C0561-002



DESICCANT REPLACEMENT For MR050 and MRS050 Series

Description:

AE01K-C0561-002 2.5lb Color Indicating Silica Gel.

The desiccant used in the MR/MRS050 series dehydrators is a distinct orange color. When exhausted it turns to a green color. Regeneration will restore the green color.

To replace the desiccant, unscrew the cap from the desiccant container. Remove the red perforated cup and felt disk. Remove the desiccant granules from the canister.

To reassemble the unit, make sure the foam disk is seated over the bottom outlet fitting in the canister. Cover the end of the tubing inside the canister and fill the unit with the desiccant refill. Shake the canister or tap on a solid surface to settle the desiccant. Place the felt disk and perforated cup on top of the desiccant. Be sure the tubing sticks through the center hole of the perforated cup. Align the tubing on the cap with internal tube, insert smaller tube into larger tube and screw the cap on tightly. The unit is now ready to be put back into service.

To regenerate the desiccant which has been removed from the unit, spread the desiccant evenly, one granule deep, on a tray. Heat for one hour at about 177°C or 350°F. The desiccant should then be cooled and stored in a tight container for future refilling of the acrylic desiccant container.



**Customer Support Center
From North America**
Telephone: 1-800-255-1479
Fax (U.S.A.): 1-800-349-5444

International
Telephone: +1-779-435-6500
Fax Number: +1-779-435-8579

Web Access
Internet: www.commscope.com
Email: #mws@commscope.com

All designs, specifications and availability of products and services presented in this bulletin are subject to change without notice.

Bulletin AE01B-A0375-002 Rev F (05/11) © 2009 - 2011 CommScope, Inc. All rights reserved
CommScope, 3 Westbrook Corporate Center, Suite 900 Westchester, IL 60154 USA